

Philips Lifeline is **recommended** for people:

- ✓ at risk of falls
- with chronic conditions
- √ with mobility problems
- recovering after discharge from hospital

How Lifeline Works:



1. Summon help

Push your Lifeline help button to connect to our response centre. If you have AutoAlert, it automatically** calls for help if you fall and can't push your button.



2. Hear a reassuring voice

We access your personal profile and assess the situation.



3. Know Help is on the way

We contact a neighbour, loved one, or emergency services and follow up to make sure help has arrived.

HomeSafe Standard

-Wireless option available

Help at the press of a button in and around your home.



HomeSafe with AutoAlert ¹

-Wireless option available

The FIRST medical alert pendant that can call for help even when you can't**.



GoSafe with AutoAlert ¹

-Wireless option available

If you lead an active lifestyle, choose our premium service, which allows you the freedom to go* where you want, when you want.



Lifeline with Wandering

Caregivers can receive smartphone notifications and updates on their loved one's whereabouts.²



^{*} Certain limitations subject to third party cellular provider availability and coverage. Signal range may vary. **AutoAlert does not detect 100% of falls. 1) Available at locally participating programs. 2. Device must be used as directed Button must be worn, adequately charged, and within range of a third-party cellular network. Availability of network not guaranteed. Tracking signal sent approx. every five (5) minutes while moving; once (1) per hour if no movement detected.

For more information, please call:

Victoria Lifeline 250-475-6415 888-832-6073

